


- ON Enciende luces
- OFF Apaga las luces
- ☀+ Aumenta luminosidad
- ☀- Disminuye luminosidad
- ⦿+ Aumenta la temperatura color
- ⦿- Disminuye la temperatura de color
- ☀ 6500K (máxima luz blanca)
- 🌙 Modo nocturno
- ⌚ Temporizador
 - *Presionar brevemente, (parpadea la luz una vez) La luz se mantendrá encendida 15 minutos.
 - *Presionar brevemente, (Parpadea 2 veces). La luz se mantendrá encendida 30 minutos.
 - *Presionar brevemente, (Parpadeo 3 veces) la función temporizador se cancela.
- Ⓐ Enciende foco A. 4000K.
- Ⓑ Enciende foco B. 4000K.
- ⒶⒷ Enciende ambos focos A y B. 4000K.

NOTA.

Si el control remoto no funciona, hay que volver a sincronizarlo con el pie de salón. Desconéctelo y vuelva a conectarlo, durante los primeros 30 segundos presione durante 10 segundos el botón OFF. Cuando parpadee la luz el mando se habrá emparejado con éxito.




La luz del pie de salón apagada a través del mando a distancia o botón táctil queda en stand-by. Quedará completamente apagado, si se corta la corriente a través del interruptor de pie.

Para ver la ficha técnica de producto completa, puede usar el siguiente código QR:



Touch button
1 press ON and colour temperature selector.
2 consecutive presses OFF.




-  **ON** Turn on lights
-  **OFF** Turns lights off
-  **Increases brightness**
-  **Decreases brightness**
-  **Increases colour temperature**
-  **Decreases colour temperature**
-  **6500K (maximum white light)**
-  **Night mode**
-  **Timer**
 - *Press briefly, (light flashes once) The light will stay on for 15 minutes.
 - *Press briefly, (Flashes 2 times). The light will stay on for 30 minutes.
 - *Press briefly, (Flashing 3 times) the timer function is cancelled.
-  **A** Switch on spotlight A. 4000K.
-  **B** Switch on spotlight B. 4000K.
-  **AB** Switch on both lamp A and B. 4000K.

IMPORTANT NOTICE.

If the remote control does not work, it must be re-synchronised with the floor lamp. Disconnect and reconnect, during the first 30 seconds press the OFF button for 10 seconds.

When the light flashes the remote will be paired successfully.



The light of the floor lamp turned off via the remote control or touch button remains in stand-by mode. It will be completely switched off if the power is switched off via the foot switch.

You may use the following QR code to view the complete technical data sheet of the product:



If you have any technical questions, please do not hesitate to contact our technical Department.
We are at your disposal in our email: export@schuller.es